




キーSW  
ON又はSTART


BAT

2W : 2WD車  
4W : 4WD車



11 B/Y  
25 B/W  
45 BR/Y  
3 R  
40 R/W

8 7 2 1 3  
6 9 5 4



8 7 11 1 2 3  
6 4 9 10 5

